



# Data Sheet

---

## RISH CON-P



Measure



Control



Record



Analyze



Optimize

### Application

The **RISH CON - P** transducer is used to measure and convert active, reactive, apparent power, Phase angle & Power Factor of a Single-phase or Three-phase AC system with balanced or unbalanced load into a proportional **load independent DC current or voltage output** signal.

### Salient Features

- True RMS measurement.
- Fully **onsite programmable** input voltage range & input current range
- On Site Configurable as Active / Reactive / Apparent Transducer / Phase Angle / Power Factor
- **Onsite selectable output type**(DC current / DC voltage)
- **Single or Dual output**
- Accuracy **Class 0.2 ( IEC / EN 60688)** for Power
- Accuracy **Class 0.5 ( IEC / EN 60688)** for Phase Angle / Power Factor
- Seven Segment **LCD Display** (Optional)
- **Rs485(Modbus)** Communication (Optional)
- Wide Auxiliary power supply  
Accepts any input between 60V-300V AC/DC or 24V-60V AC/DC
- Output Response Time < 750 ms standard
- Fast and easy installation on DIN RAIL or onto a wall or in a panel using optional screw hole bracket
- Connection Terminal : Conventional Screw type.

### Product Features

#### Measuring Input:

AC Voltage/Current input signal,sine wave or distorted wave form.

#### Analog Output (Single or dual):

Isolated analog output which can be set to voltage or current output onsite.

#### Accuracy:

Output signal accuracy **class 0.2** as per International **IEC / EN 60688** Standard.

#### Programmable Input/Output:

The Transducer can be programmed onsite using front key & display or through programming port (COM) or through RS 485.

#### LED Indication:

LED indication for power on and output type.  
(Current output : Red LED, Voltage output : Green LED).



Fig. 1 RISH CON - P

#### Display Module(Optional):

Optional 7 segment LCD display with backlit & keypad. For displaying measured parameter & onsite configuration of Input/output.

#### RS485 Communication(Optional):

Optional RS485 communication is available. For reading measured parameter & onsite configuration of input/output.

#### Symbols and their meaning:

X	Input
	Apparent /Active/Reactive
	Power Factor / Phase Angle
X0	Start value of input
X1	Elbow value of input
X2	End value of input
Y	Output DC Voltage / DC Current
Y0	Start value of output DC
	Voltage / DC Current
Y1	Elbow value of output DC
	Voltage / DC Current
Y2	End value of output DC
	Voltage / DC Current
R <sub>N</sub>	Rated value of output burden
F <sub>N</sub>	Nominal Frequency



Measure



Control



Record



Analyze



Optimize

### Technical Specifications

#### Measured Parameter

Active Power / Reactive Power / Apparent Power / Power Factor /Phase Angle.

**Network Type Supported by Power transducer:** Single Phase / 3 phase 3 wire Unbalanced / 3 phase 4 wire Unbalanced  
3 phase 3 wire balanced / 3 phase 4 wire balanced

**Network Type Supported by Power Factor & Phase Angle :** Single Phase / (U12 I1) 3 Phase Balanced load  
(U13 I1) 3 Phase Balanced load / (U23 I1) 3 Phase Balanced load  
3 phase 3 wire balanced / 3 Phase 4 wire Balanced load

#### Nominal Voltage Input( $U_N$ ):

Nominal input Voltage (AC RMS)  
(PT Secondary range)  $100\text{ V} \leq U_N \leq 500\text{ VL-L}$

PT Primary range 100V to 692.8 KVL-L

Nominal Frequency  $F_N$  25 Hz to 65 Hz

Nominal input Voltage burden  $< 0.6\text{ VA}$  per phase at  $U_N$

Overload Capacity:  $1.2 * U_N$  continuously,  
 $2 * U_N$  for 1 second, repeated 10 times at 10 minute intervals  
( $U_N$  maximum 300V with power supply powered from measuring input).

#### Nominal Current Input( $I_N$ ):

Nominal input Current (AC RMS)  
(CT Secondary range)  $1\text{ A} \leq I_N \leq 5\text{ A}$

CT Primary range 1 A to 9999 A

Nominal Frequency  $F_N$  25 Hz to 65 Hz

Nominal input Current burden  $< 0.2\text{ VA}$  per phase at  $I_N$

Overload Capacity:  $1.2 * I_N$  continuously,  
 $10 * I_N$  for 3 second, repeated 5 times at 5 minute intervals.  
 $50 * I_N$  for 1 second, repeated 1 times at 1 hour interval(M ax 250 A).

#### Allowed measuring range end values X2 (calibration factor Xc):

With single phase AC active/reactive/apparent power  $0.30 \leq (X2/\text{Rated Power}) \leq 1.3 * U_N / \sqrt{3} * I_N$

With 3-phase AC active/reactive/apparent power  $0.30 \leq (X2/\text{Rated Power}) \leq 1.3 * \sqrt{3} * U_N * I_N$

(For single phase Rated Power= $U_N / \sqrt{3} * I_N$ )

(For Three phase Rated Power= $\sqrt{3} * U_N * I_N$ )

#### Phase Angle & Power Factor measuring Range:

Minimum span  $20^\circ$  to Maximum Span  $360^\circ$

#### Measuring Output Y( Single or Optional Dual):

Output type Load independent DC Voltage , DC Current

On site selectable through DIP switches.

Load independent DC output Unipolar 0...20mA / 4...20mA OR 0...10V.

Bipolar -20mA....0....+20mA OR -10V....0....+10V

Output burden with DC current output  
Signal  $0 \leq R \leq 15V/Y2$

Output burden with DC voltage output  
Signal  $Y2/(2\text{ mA}) \leq R \leq \infty$



Measure



Control



Record



Analyze



Optimize

Current limit under overload R=0	$\leq 1.25 * Y2$ with current output $\leq 100$ mA with voltage output
Voltage limit under R= $\infty$	$< 1.25 * Y2$ with voltage output $\leq 30$ V with current output
Residual Ripple in Output signal	$\leq 1\%$ pk-pk
Response Time	$< 750$ ms
Measurement TRMS	Up to the 15th harmonic

### Auxiliary Power Supply:

AC/DC Auxiliary Supply	60V... 300 VAC-DC $\pm 5\%$ or 24V...60V VAC-DC $\pm 10\%$
AC Auxiliary supply frequency range	40 to 65 Hz
Auxiliary supply consumption	

60V...300 VAC-DC	$\leq 8$ VA for Single output $\leq 10$ VA for Dual output
24V...60 VAC-DC	$\leq 5$ VA for Single output $\leq 6$ VA for Dual output

### Accuracy :( Acc. to IEC / EN 60688)

Reference Value	Output end Value Y2 (Voltage or Current)
Basic Accuracy for power transducer	$0.2 * C$

Basic Accuracy for Phase Angle & Power Factor transducer  $0.5 * C$

Factor C (The highest value applies if calculated C is less than 1, then C=1 applies)

<p>Linear characteristics:</p> $C = \frac{1 - \frac{Y0}{Y2}}{1 - \frac{X0}{X2}} \text{ or } C=1$	<p>Bent characteristics:</p> <p>For <math>X0 \leq X \leq X1</math> <math>C = \frac{Y1 - Y0}{X1 - X0} \cdot \frac{X2}{Y2} \text{ or } C=1</math></p> <p>For <math>X1 \leq X \leq X2</math> <math>C = \frac{1 - \frac{Y1}{Y2}}{1 - \frac{X1}{X2}} \text{ or } C=1</math></p>
--	--

### Reference conditions for Accuracy :

For Power Transducer:

Ambient temperature	23°C +/- 1°C
Pre-conditioning	30 min acc. to IEC / EN 60688
Input Variable	Voltage Rated / Current Rated
Input waveform	Sinusoidal, Form Factor 1.1107
Input signal frequency	50 or 60Hz
Active / Reactive factor	Cos $\Phi=1$ resp. Sin $\Phi = 1$

For Phase Angle & Power Factor Transducer:

Reference Value For Phase angle = 90° resp. For power factor = 0.5

Auxiliary supply voltage	At nominal range
Output Load	Rn = 7.5 V / Y2 $\pm 1\%$ With DC current output signal Rn = Y2 / 1 mA $\pm 1\%$ With DC voltage output signal
Miscellaneous	Acc. to IEC / EN 60688



Measure



Control



Record




Analyze



Optimize

### Output Characteristics:

Example of setting with Linear Characteristics :




X0 = Start value of input  
Y0 = Start value of output  
X1 = Elbow value of input

Y1 = Elbow value of output  
X2 = End value of input  
Y2 = End value of output

**Note:** End value(Y2) of output cannot be changed onsite.

Example of setting with bent Characteristics :



### Additional Error:

Temperature influence

$\pm 0.2\%/10^{\circ}\text{C}$

### Influence of Variations:

As per IEC / EN 60688 standard.

Output stability

< 30 min

### Safety:

Protection Class  
Protection

II (Protection Isolated, EN 61010)  
IP 40, housing according to EN 60 529  
IP 20 ,terminal according to EN 60 529

Pollution degree  
Installation Category  
Insulation Voltage

2  
III  
1min. ( EN 61010-1)  
7700V DC, Input versus outer surface  
5200V DC, Input versus all other circuits  
5200V DC, Auxiliary supply versus outer surface and output  
690V DC, Output versus output versus each other versus outer surface.

### Installation Data:

Mechanical Housing

Lexan 940 (polycarbonate)  
Flammability Class V-0 acc. To UL 94, self extinguishing,  
non dripping, free of halogen  
Rail mounting / wall mounting  
Approx. 0.4kg

Mounting position  
Weight

### Connection Terminal

Connection Element

Conventional Screw type terminal with indirect wire pressure

Permissible cross section  
of the connection lead

$\leq 4.0 \text{ mm}^2$  single wire or  $2 \times 2.5 \text{ mm}^2$  fine wire



Measure



Control



Record



Analyze



Optimize

### Environmental:

Operating temperature	0°C... <u>23°C</u> ...45°C(usage Group II)
Storage temperature	-40 °C to 70 °C
Relative humidity of annual mean	≤ 75%
Altitude	2000m max

### Ambient tests:

EN 60 068-2-6	Vibration
Acceleration	± 2 g
Frequency range	10...150...10Hz,
Rate of frequency sweep	1 octave/minute
Number of cycles	10, in each of the three axes
EN 60 068-2-7	Shock
Acceleration	3 x 50g 3 shocks in each direction

IEC 1000-4-2/-3/-4/-5/-6 EN 55 011	Electromagnetic compatibility.
---------------------------------------	--------------------------------

### LED Indication:

ON LED	Aux.supply healthy condition	Green LED continuous ON
O/P1 LED	Output1 voltage selection	Green LED continuous ON
	Output1 current selection	Red LED continuous ON
O/P2 LED	Output2 voltage selection	Green LED continuous ON
	Output2 current selection	Red LED continuous ON

### Electrical Connections:

Connection	Terminal details	
Measuring Voltage Input	UL1	2
	UL2	5
	UL3	8
	N	11
Auxilliary Power supply	~ , +	13
	~ , -	14
Measuring output - 1	+	15
	-	16

Connection	Terminal details	
Measuring Current Input	I1	1
	I1'	3
	I2	4
	I2'	6
	I3	7
	I3'	9
Measuring output - 2	+	17
	-	18



Measure



Control



Record



Analyze




Optimize


### Electrical Networks

<b>3 Phase 4 Wire Unbalanced Load</b>	
<b>3 Phase 3 Wire Unbalanced Load</b>	
<b>3 Phase 4 Wire Balanced Load</b>	
<b>3 Phase 3 Wire Balanced Load</b>	
<b>1 Phase 2 Wire</b>	
<b>U12 I1 3 Phase Balanced Load</b>	
<b>U13 I1 3 Phase Balanced Load</b>	
<b>U23 I1 3 Phase Balanced Load</b>	

### Terminal Details



### Dimensions



Measure



Control



Record



Analyze



Optimize

### Programming (Figs.4 and 5)

#### Programming of transducer can be done in three ways :

- 1) Programming Via Front LCD & two keys for with display model.
- 2) Programming Via optional RS485(MODBUS) communication port. ( Device address,PT Ratio,CT Ratio,Transducer type>Password, communication parameter,Output Type & simulation mode can be programmed).
- 3) Programming Via Programming port available at front of RISH CON Transducers using optional PRKAB601 Adapter.

#### Programming Via Programming port (COM)

A PC with RS 232 C interface along with the programming cable PRKAB601 and the configuration software are required to program the transducer.

#### The connections between

PC ↔ PRKAB 601 ↔ Rish CON Transducer.

The powersupply mustbe applied to transducer before it can be programmed.




Fig. 4

The Configuration software is supplied on a CD. The programming cable PRKAB601 adjusts the signal level and provides the electrical insulation between the PC and RISH CON Transducers.

#### Configuring RISH CON Transducer :

To configure RISH CON Transducer Input / Output one of the three programming methods can be adapted along with mechanical switch setting (DIP switch setting on PCB).

#### DIP Switch Setting for OUTPUT :

Type of output (current or voltage signal) has to be set by DIP switch (see Fig.5).

For programming of DIP switch the user needs to open the transducer housing & set the DIP switch located on PCB to the desired output type Voltage or Current. Output range changing is not possible with DIP switch setting.

Refer below Fig. 5 for DIP switch setting.

The four pole DIP switch is located on the PCB in the RISH CON Transducer

DIP Switch Setting	Type of Output Signal
	load-independent current
	load-independent voltage

Fig. 5



Measure



Control



Record



Analyze



Optimize



### Ordering Information

ProductCode	CP41-	X	X	XX	XX	X	X	X	X	X	00
Model	ProgrammablePowerTransducer	P									
Systemtype	4WUB(OnsiteSelectable1Ph.2W, 3Ph.3W/4W&Balanced/ Unbalanced)	3									
InputVoltage	Programmable100...500V	8F									
InputCurrent	Programmable1...5A	75									
PowerSupply	60-300VAC/DC 24-60VAC/DC				H F						
Output	1O/P 2O/P					1 2					
DisplayModule	WithDisplay WithoutDisplay						D Z				
RS485Module	WithRS-485 WithoutRS-485							R Z			
ProgrammingCable	With-PRKAB601 Without-PRKAB601								C Z		

**Ordering Example**—CP41-P38F75F1DRZ00—RishCONP, Programmable power transducer, 3Phase4Wire, 100...500VAC, 1...5A, Aux24-60VAC/DC, 1O/P, Withdisplay, WithRS485, Without-PRKAB601

Analog DC output options as below, to be specified while ordering only

Current Output	Voltage Output	DI Option
Standard Ranges		
0/4...20mA	0...10V	Yes
-20...0...20mA	-10...0...10mA	
Optional factory set ranges		
0...10mA	0...5V	No
0...5mA	0...2.5V	No
0...2.5mA	0...1V	No
0...1mA		

Note:

1. End value of output cannot be changed on site.
2. -20...0...20mA and -10...0...10V output ranges are not applicable for Apparent power.



Measure



Control



Record



Analyze



Optimize



RISHABH



Measure



Control



Record



Analyze



Optimize

## RISHABH INSTRUMENTS LTD.

Domestic (India): +91 253 2202028/99 | [marketing@rishabh.o.in](mailto:marketing@rishabh.o.in)

International: +91 253 2202004/06/08/99 | [global@rishabh.co.in](mailto:global@rishabh.co.in)

[www.rishabh.co.in](http://www.rishabh.co.in)