Analogue Power Meters Active - Reactive (WQ)

WQ 96 WQ 144

Data Sheet

Analogue Power Meters 90°Scale



Application

The Watt meters, WQ96/144 are offered for the AC systems -single phase

- -3 phase balanced load 3 or 4 wire
- -3 phase unbalanced load 3 or 4 wire

These instruments are suitable to indicate forward (export / out going) and reverse (import / in coming) power flow. They can be used both on sinusoidal and non - sinusoidal current

These meters offer several advantages in Switchboard and Generating Set panels. Number of meters can be mounted in a single Cut out (Mosaic Mounting). The Bezel, Front window glass and Dial can be easily replaced


Features

- · Linear scale.
- · Knife edge pointer.
- · Glass filled polycarbonate housing
- · Easily replaceble glass and bezel.
- Easy installation with swivel screws.

Functional Principle

For active and reactive power measurement, a moving-coil indicator is used to indicate watts and vars for which an analogue DC signal is obtained from a power converter attached to the case of the indicator.

Schematic diagram.



The power converter uses one, two or three for multiplier systems (2) depending on the measurement of balanced or unbalanced load AC systems. Current transformers (1) provide the input current to the multiplier circuit.

The multipliers form the product of the instantaneous values of current and voltage (TDM principle). The product resultant is integrated, thereby suppressing the AC ripple. Subsequently product proportional output is delivered to (3). There the voltage is converted into Current, whose magnitude also depends on Feasibility Factor (λ).

Finally this current is fed to the moving coil movement, (4).

For the instrument DC power supply is obtained from input voltage, **(5)**.

Specifications

Scale and Pointer

Pointer Knife pointer
Pointer deflection 0 ... 90°
Scale characteristics Linear
Scale di vision Coarse-fine
Scale length WQ96 WQ144
97mm 146mm

Mechanical Data

Case material

Case details Moulded square case suitable for

mounting in Control / Switchgear panels, Machinery consoles.

panels, Machinery consoles.
Glass filled polycarbonate,

flame retardant and drip proof

as per UL 94 V-0.

Front facia Glass
Colour of be zel Black
Position of use Vertical
Panel fixing Swivel screws.

Mounting Stackable in a single cutout

Panel thickness ≤ 25 mm

Terminals Hexagon studs, M4 screws and

wire clamps E3

Electrical Data

Measured quantity Active / Reactive Power

Response time 4s max.

Overload capacity (acc to IS: 1248/ IEC 51/ DIN EN 60051)

Continuously 1.2 times rated voltage / current

Short duration 2 times rated voltage , 5 Sec max

10 times rated current ,5 Sec max

Power consumption(Approx)

Current path ≤ 0.25 VA

Voltage path types

E1W, D1W, D1B, V1W, V1B ≤ 3.0 VA E1B ≤ 3.5 VA D2W, D2B ≤ 3.4 VA V3W ≤ 3.9 VA V3B ≤ 4.3 VA Enclosures code IP 52 case

(IEC 529) IP 00 for terminals

insulation class Group A according to VDE 0110

Rated insulation voltage 660 V Proof voltage testing 2 kV

Installation catagory 300 VCAT III

(IEC 1010)

insulation resistance > 50 Mohm at 500 V d.c.

Accuracy at Reference Conditions

Accuracy class 1.5 according to IS:1248

(IEC 51/ DIN EN 60051)

Reference conditions

Ambient temperature 23 $^{\circ}$ $^{\circ}$ $^{\circ}$ $^{\circ}$ 2 $^{\circ}$

Position of use Nominal position $\pm 1^{\circ}$

Input Full-scale power value Pw or Pb Feasibility factor "Lambda"=Pw/Ps or Pb / Ps Power factor $\cos \varphi = 1 \pm 0.01$ for Watt meters &

Sin ϕ = 1 ± 0.01 for Var meters

Voltage Rated voltage + 2%

 $\begin{array}{lll} \mbox{Frequency} & 45\text{-}65 \mbox{ Hz } \pm 0.1\% \mbox{ for E1B}) \\ \mbox{Current} & 20\% \mbox{ to } 120\% \mbox{ of rated current} \\ \mbox{Others} & \mbox{IS: } 1248 \mbox{ (IEC } 51/\mbox{ DIN EN } 60051) \\ \end{array}$

Electrical and mechanical zero point in the meter are not necessarily identical. Zero adjustment should be done when only voltage is applied and current circuit not energised.

Nominal range of use

Ambient temperature 0 ... 50 ℃

Position of use Nominal position $\pm 5^{\circ}$

External magnetic field 0.5 mT

Voltage Rated voltage ± 15%

Power factor Cos φ = 1 to 0.5 (ind.) for active power

Sin φ = 1 to 0.5 (ind.) for reactive power

Frequency 45-65 Hz (50 Hz \pm 1% for E1B)

Environmental Conditions

Climatic suitability Climate category II as per IS: 1248

(climatic class 3 according to

VDE / VDI 3540)

Operating temperature -10 ... + 55 ℃ Storage temperature -25 + 65 ℃

Relative humidity < 75% annual average, non-condensing

Shock resistance 15g. 11ms

Vibration resistance 10-55-10 Hz/0.15 mm

1.5 g at about 50 Hz.

Standard Measuring Ranges

Active power Reactive power

Single phase system E1W E1B 3 phase 3 wire system balanced load D1W D1B 3 phase 4 wire system balanced load V1W V1B 3 phase 3 wire system unbalanced load D2W D2B 3 phase 4 wire system unbalanced load V3W V₃B

selection of measuring range

Apparant power Ps is calculated from primary ratings of current transformer and voltage transformer.

In single phase network, Ps = V . I

where V = voltage between phase and neutral & I = line current. In three phase network, Ps = v3 V . I

where V = voltage between two phase & I = line current.

Full scale value i.e range of the instrument (Pw = active power, Pb = reactive power) must be selected in such a way that the same remain between 0.5 times and 1.2 times the value of apparent power Ps.

Thus feasibility factor "Lambda" should be between 0.5 and 1.2 where "Lambda" = Pw/Ps or Pb/Ps

Full scale values shall preferably be selected from standard series according to DIN 43701, 1-1.2-1.5-2-2.5-3-4-5-6-7.5-8 and their decadic / decimal multiples.

Rated voltage:-

:- 57.7, 63.5, 100, 110, 127, 220, 289, 380,500V. For Single phase(E1W, E1B)

For Three phase (D1W, D1B, 100, 110, 220, 240, 380, 415,

D2W, D2B, V1W, V1B, V3W, V3B)

The voltage will be considered as a phase voltage (between phase and neutral) in case of single phase meters and as a line voltage (between two phases) in case of multi phase (2 wire, 3 wire and 4 wire) meters.

Rated current:-1A OR 5 A

> If used on current transformer. please state transformer ratio on the

order.

Applicable Standards

Nominal case and cutout dimensions for : IS 2419 indicating electrical instruments. DIN 43700 Scale and pointer for electrical IS 1248 measuring instruments. DIN 43802 Connections and Terminal markings for IS 1248

panel meters.

Terminal bolts / leads Clamp straps for connections. DIN 43807

DIN 46200/46282

DIN 46282

Safety requirements and protective measures for Electrical indicating instruments and their acessories.

DIN 40050 / 8-70 VDE 0110 /11-72 VDE 0410 /10-76

IS 9249

IEC 529,IEC 1010

Performance specifications for direct IS 1248

acting indicating analogue electrical

IEC 51/DIN EN 60051

measuring instrumentsand their accessories Front frames for indicating measuring

DIN 43701 DIN 43718

instruments principle dimensions.

Technical conditions of delivery for DIN 43701

electrical instruments.

UL Combustibility class. UL 94 V-O Mechanical strength (Free fall test, IS 1248, IEC 51 vibration test)

IS 9000

VDE 0411, part I, Sec.43/44.IEC 1010

Environmental conditions : IS: 1248

> IS: 9000, Part 5,7,8 VDE / VDI 3540

Electro Magnetic Compatibility(EMC)Compliance as per following standards:-EN 50081-2,EN 50082-2,EN 55011/CISPR 11,

> EN 60555-2,IEC 555-2, EN 61000-4-4 / IEC 1000-4-4, EN 61000-4-2 / IEC 1000-4-2,

EN 61000-4-5 / IEC 1000-4-5, ENV 50140.

Comlpy with following European directives: 89/336/EEC(EMC directive),73/23/EEC(low voltage directive)&amendment 93/68/EEC. for CE marking.

Options

Case

Front facia Antiglare glass Colour of bezel

Red, Yellow, Blue, White Red index pointer Front adjustable on site Position of use on request 00....180 °

Dial

Blank dial With initial and end values marked.

Special markings Numbering /Lettering.


Division dials Basic divisions without numbering.

Colour markings/bands Red or green.


Safety Precautions


- · Instruments with damaged bezels or window glasses must be disconnected from mains.
- Adequate safety clearance must be maintained to control panel fasteners and to sheet metal housing, if non - insulated connector wires are used.
- Scales should be replaced under Voltage- free conditions.
- Bezels and window glasses should be replaced under Voltage - free conditions

Connections




Reactive Power E1B-single phase (one element)






V1VV-Three phase, four-wire AC supply with balanced load(one element)




D1B -Three phase,three-wire AC supply with balanced load


V1B -Three phase, four-wire AC supply with balanced load(one element)




D2W-Three phase,three- wire AC supply with unbalanced load (two element)




D2B -Three phase,three- wire AC supply with unbalanced load (two element)




V3W-Three phase,four-wire AC supply with unbalanced load(three element)





V3B.Three phase,four-wire AC supply with unbalanced load(three element)





Dimensions





Dimensions (in mm)		WQ 96	WQ 144
Bezel Case Depth	a b c * d e	96 90 106 91.5 5.5	144 136 106 137.5 5.5
Cotout Size		92 ^{+0.8}	138 ⁺¹
Depth with Back cover	f **	64	64
Weight (approx.)		0.65-0.9 kg.	0.9-1.1 kg

Ordering Information

Type WO	Watt and Var meter,90° Scale	
Front dimension 96 and 144	96 mm x 96 mm 144mm x 144mm	
Type E1W E1B D1 W D1B V1W V1B D2W D2B V3W V3B	Single phase systems 3 phase 3 wire system balanced load 3 phase 4 wire system balanced load 3 phase 3 wire system unbalanced load 3 phase 4 wire system unbalanced load	
Measurng ranges	Specify while ordering	
Rated voltages	Refer to table inside	
Rated currents	1A, 5A	
Front facia	Normal glass ^{*1} Antiglare glass ^{*3}	
Colour of bezel	Black ^{'1} Red,Blue,Yellow,White ^{'3}	
Position of use	Vertical On request 0 180° 3	
Dial	Standard scale same as measuring range " Blank dial with division " Additional lettering on request " Additional numbering on request " Coloured marking red or green " Coloured sector red or green "	
Logo	RISHABH ^{*1} , for Indian sales C.G. ^{*1} , export through Crompton Greaves I.D. Others ^{*3}	

^{*1} standard

Ordering Example

WQ 96 V3W for active power 3 phase 4 wire system unbalanced load,measuring range 0 \dots 480 kW, voltage AC 440 V, for use on current transformer 600/5A.

Specifications are subject to change without notice(11/11)





RISHABH INSTRUMENTS PVT.LTD.
F-31, MIDC, Satpur, Nashik-422 007,India.
Tel.: +91 253 2202160, 2202202 Fax: +91 253 2351064
E-mail: India:- marketing@rishabh.co.in
International:- exp.marketing@rishabh.co.in
www.rishabh.co.in

^{*3} Please clearly add the desired specifications while ordering